


SIRRA


08-12-2015






base plate dimensions





DIMENSIONS




MOUNTING INSTRUCTION

- 1 Mount the base plate to the housing with screws
- 2 Attach the base plate + housing to the ceiling with screws

POWER CONNECTION


Interior: STANDARD version driver for LED is included





- Insert the outer part of the inset module into the SIRRA by turning the springs up
- (5) Insert the lamp into the inner part of the inset module and fix with spring
- Click the inner part of the inset module into the outer part

SIRRA


08-12-2015







DIMENSIONS




MOUNTING INSTRUCTION

- 1 Mount the base plate to the housing with screws
- 2 Attach the base plate + housing to the suspension base

POWER CONNECTION

Interior: STANDARD version driver for LED is included



- Mount the suspension base of the SIRRA to the ceiling with screws
- (5) Insert the outer part of the inset module into the SIRRA by turning the springs up
- (a) Insert the lamp into the inner part of the inset module and fix with spring
- Click the inner part of the inset module into the outer part