



DOCUS SUSPENDED

13-Sep.-2018










DIMENSIONS



MOUNTING INSTRUCTION

- (1) ONLY FOR LED: mount the LED module into the suspension set.
- (2) Insert part A until it clicks in the lower part of the cover
- 3 Insert part B until it clicks in the higher part of the cover
- 4 POWER CONNECTION

Connect wiring to the power supply (for LED) or to terminal block (for PAR16)

PARALLEL CONNECTION




Mount the ceiling base on the celing

(You have to turn the cover counterclockwise a quarter in order to loosen it from the ceiling base and mounting back on is by turning clockwise.)


6 ONLY FOR PAR16 Insert the lamp


NEW CEILING BALDACHIN ROUND


29-Feb.- 2016




mounting plate dimension:







DIMENSIONS




MOUNTING INSTRUCTION


- Remove the mounting plate from the baldachin cover. Fix the mounting plate on the ceiling with screws.
 - * There are two wiring method:
 - Method 1: the lamp cables go through the wall of the Mounting plate;
 - Method 2: the lamp cables go through the bottom of the Baldachin cover.
- (2) Make holes on the Baldachin cover for lamp cables.
- 3 Put the grommets into the holes. (This step applies to the Method 2.)
- 4 Adjust the cables of luminaire to desired length, tighten the strain reliefs
- **(5)** Connect the luminaire cables into the terminals.

6 POWER CONNECTION When the luminaire number

is less than 5



When the luminaire number is greater than 4




Baldachin cover earthing connector:





Hang the strain reliefs on the holders.

NEW CEILING BALDACHIN ROUND

29-Feb.- 2016











27-Jul.- 2016















DIMENSIONS




MOUNTING INSTRUCTION

- Remove the mounting plate from the baldachin cover.
- Adjust the cable of lights to desired length. If you need the lights be horizontal alignment, the baldachin cover can be a helpful judgement tool.
- Fix the mounting plate on the ceiling with screws.

 If you need to align the orientation of the light, fine-tuning of strain relief direction to achieve adjustment.
- 4 POWER CONNECTION

Connect the power




Baldachin cover earthing plug:





- S Lock the baldachin cover on the mounting plate with two plastic screws.
- 6 Put the silicon eyelets in the cable outlets.


27-Jul.- 2016















DIMENSIONS




MOUNTING INSTRUCTION

- Remove the mounting plate from the baldachin cover.
- Adjust the cable of lights to desired length. If you need the lights be horizontal alignment, the baldachin cover can be a helpful judgement tool.
- Fix the mounting plate on the ceiling with screws.

 If you need to align the orientation of the light, fine-tuning of strain relief direction to achieve adjustment.

(4) POWER CONNECTION

Connect the power




Baldachin cover earthing plug:





- Lock the baldachin cover on the mounting plate with two plastic screws.
- 6 Put the silicon eyelets in the cable outlets.


of the luminaires at the same height.


27-Jul.- 2016












DIMENSIONS




MOUNTING INSTRUCTION

- (1) Remove the mounting plate from the baldachin cover.
- Adjust the cable of lights to desired length.

 If you need the lights be horizontal alignment, the baldachin cover can be a helpful judgement tool.
- Fix the mounting plate on the ceiling with screws. If you need to align the orientation of the light, fine-tuning of strain relief direction to achieve adjustment.

(4) POWER CONNECTION

Connect the power




Baldachin cover earthing plug:




- Lock the baldachin cover on the mounting plate with two plastic screws.
- 6 Put the silicon eyelets in the cable outlets.

LIGHTING


27-Jul.- 2016




mounting plate dimension:




1




2



3



DIMENSIONS




MOUNTING INSTRUCTION

- Remove the mounting plate from the baldachin cover.
- Adjust the cable of lights to desired length. If you need the lights be horizontal alignment, the baldachin cover can be a helpful judgement tool.
- Fix the mounting plate on the ceiling with screws. If you need to align the orientation of the light, fine-tuning of strain relief direction to achieve adjustment.

POWER CONNECTION

Connect the power



Baldachin cover earthing plug:



- Lock the baldachin cover on the mounting plate with two plastic screws.
- Put the silicon eyelets in the cable outlets.